Install the oil pump and tighten the bolts.

TORQUE: 8–12 N·m
(0.8–1.2 kg-m, 6–9 ft-lb)

Assemble the crankcase (page 12-4).



(1) OIL PUMP

FINAL DRIVE OIL

CHECK

Place the motorcycle on its center stand. ıd on level ground.

Remove the oil filler cap.

Check that the oil level reaches the lower edge of the oil filler cap hole.

Check for leaks, if the level is low. Pour fresh oil through the oil filler hole until it reaches the lower edge.



(1) OIL FILLER CAP

(2) OIL DRAIN PLUG

CHANGE

Remove the oil filler cap.
Remove the drain bolt to drain all oil from the final gear case.

Install the drain bolt securely.

Fill the gear case with the recommended oil up to the correct level see above check.

OIL CAPACITY: 120 cc (4.1 oz)

RECOMMENDED OIL: HYPOID GEAR OIL
API, GL–5 SAE #90 (Above 5°C/41°F)
SAE #80 (Below 5°C/41°F)



(3) OIL LEVEL

CONTROL CABLE LUBRICATION

Periodically, disconnect the throttle cables at their upper ends. Thoroughly lubricate the cables and their pivot points with a commercially available cable lubricant or a light weight oil.