CARBURETOR SEPARATION

Loosen the synchronization adjusting screw and remove the spring.

Remove the screws attaching the carburetors together.



Carefully separate the No. 1 and No. 2 carburetors.

Remove the throttle link thrust spring.

Remove the fuel tubes and T-fitting.



Loosen the throttle stop screw.

Remove the nut attaching the throttle drum and remove the throttle drum and return spring.

CARBURETOR ASSEMBLY

Install the throttle return spring, throttle drum and nut.

Tighten the nut securely.